

# Advantage IV

**Gold Series** GTx108-F(/SI & /DI)

## **OVERVIEW**

## SWSI & DWDI Airflow Measurement with Temperature and Alarm Capability



- Thermal Dispersion Technology
- Designed for SWSI and DWDI Fans
- NIST-traceable Calibration
- %-of-reading Accuracy
- Airflow and Status Alarm
- Temperature Output Capability
- Combination Analog/Network Models
- Throat, Face, and Forward Mounting
- Remote Transmitter with LCD Display
- 3-year Warranty











The GTx108-F/SI and GTx108-F/DI are EBTRON's solution for accurate and repeatable airflow measurement in SWSI and DWDI fans. Airflow, temperature and/or airflow alarming are available on all models. Does not affect fan performance. Bluetooth low energy technology interface.

## **Typical Applications**

- Fan Airflow Tracking
- Air Change Verification & Monitoring
- Fan Performance Monitoring

#### **Benefits**

- Demonstrate Fan Performance and Operation
- ♦ Improve Fan Tracking on **VAV Systems**
- ♦ Comply with ASHRAE Standards
- Save Energy
- Reduce Fan Horsepower

### **Product Highlights**

- Accurate and Repeatable
- Long-term Stability
- Streamline Design
- Adjustable Mounting **Brackets**
- "Plug and Play" Operation
- Intuitive User Interface
- **FEP Plenum Rated Cables**



# SPECIFICATIONS: GTx108-F(/si & /DI)

#### General

**Probe and Sensor Node Configurations** 

**SWSI** and **DWDI** fans: 2 probes x 1 sensor node/per probe in each fan inlet

Installed Airflow Accuracy<sup>1</sup>

 $\pm$ (3% to 10%) of reading, depending on fan type and installation. May be improved by field adjustment using the Field Adjust Wizard (FAW) to a reliable reference.

**Sensor Node Averaging Method** 

Airflow: Independent, arithmetic average

Temperature: Independent, velocity weighted or arithmetic average

**Listings and Compliance** 

UL: UL-873 and CSA C22.2 No. 24

**CE**: European shipments only (*EB-Link* not available) **BACnet International**: BTL Listed (GTC108 and GTM108

transmitters)

FCC: This device complies with Part 15 of the FCC rules

RoHS: This device is RoHS2 compliant

**Environmental Limits** 

Temperature:

Probes: -20 to 160 °F [-28.9 to 71.1 °C]
Transmitter: -20 to 120 °F [-28.9 to 48.9 °C]

Humidity: (non-condensing)
Probes: 0 to 100%
Transmitter: 5 to 95%

#### **Individual Sensing Nodes**

**Sensing Node Sensors** 

Self-heated sensor: Precision, hermetically sealed, bead-in-glass

thermisto

Temperature sensor: Precision, hermetically sealed, bead-in-glass

thermistor

**Sensing Node Housing** 

Material: Glass-filled Polypropylene

Sensor Potting Materials: Waterproof marine epoxy

Airflow Measurement

Accuracy: ±2% of reading to NIST-traceable airflow standards

(includes transmitter uncertainty)

Calibrated Range: 0 to 10,000 fpm [0 to 50.8 m/s]

Calibration Points: 16
Temperature Measurement

Accuracy: ±0.15°F to NIST-traceable temperature standards

(includes transmitter uncertainty)

Calibrated Range: -20 to 160 °F [-28.9 to 71.1 °C]

**Calibration Points: 3** 

#### Sensor Probe Assembly

**Mounting Rods** 

Material: Zinc plated steel

Mounting Brackets

Material: 304 stainless steel
Mounting Options & Size Limits

Throat: 6 to 66 inches [152.4 to 1676.4 mm] (throat diameter)
Forward: 6 to 64 inches [152.4 to 1625.6 mm] (diameter at inlet

entrance)

Face: 11 to 77 inches [279.4 to 1955.8 mm] (diameter at inlet

entrance)

#### **Probe to Transmitter Cables**

Type: FEP jacket, plenum rated CMP/CL2P, UL/cUL listed, -67 to

302 °F [-55 to 150 °C], UV tolerant

Standard Lengths: 10, 25, and 50 ft. [3.1, 7.6 and 15.2 m]
Connecting Plug: 9/16" [14.29 mm] nominal diameter with gold-

plated connector pins

#### **Transmitter**

Power Requirement: 24 VAC (22.8 to 26.4 under load) @16V-A Connector Receptacle Pins and PCB Connections: Gold-plated receptacle pins, PCB interconnects, PCB edge fingers, and test points User Interface: 16-character LCD display and 4 button interface

**B.A.S. Connectivity Options** 

GTC108 Transmitter: Two field selectable (0-5/0-10 VDC or 4-20mA), scalable and isolated analog output signals (AO1=airflow, AO2=temperature or alarm) plus one field selectable (BACnet MS/TP or Modbus RTU) and isolated RS-485 network connection- Individual sensor node airflow rates and temperatures are available via Modbus only

GTM108 Transmitter: Two field selectable (0-5/0-10 VDC or 4-20mA), scalable and isolated analog output signals (AO1=airflow, AO2=temperature or alarm) plus one isolated Ethernet (simultaneously supported BACnet Ethernet or BACnet IP, Modbus TCP and TCP/IP) network connection - Individual sensor node airflow rates and temperatures are available via Modbus only GTL108 Transmitter: One isolated Lonworks Free Topology network connection

GTD108 Transmitter: One USB connection for thumb drive datalogging of sensor airflow and temperature over specified time intervals

#### Airflow Alarm

Type: Low and/or high user defined setpoint alarm

Tolerance: User defined % of setpoint

**Delay:** User defined

Zero Disable: Alarm can be disabled when the airflow rate falls

below the low limit cutoff value (unoccupied periods)

Reset Method: Manual or automatic Visual Indication: Yes, LCD display

**Network Indication:** Yes (GTM108 and GTC108 only) **Analog Signal Indication:** Yes, on AO2 assignment

System Status Alarm

Type: Sensor diagnostic system trouble indication

Visual Indication: Yes, LCD display

Network Indication: Yes

Analog Signal Indication: Yes, on AO2 assignment

EB-Link Bluetooth Interface for Android® and iPhone®: Download individual sensor node airflow/temperature data, settings and diagnostics

GTx108\_F\_SI\_DI\_Overview

<sup>&</sup>lt;sup>1</sup> Installed airflow accuracy is the actual system accuracy expected and includes sampling uncertainty of the sensor probes.